

User Manual

FP50 Motherboard/MTN-FP50 Mini PC

A decorative graphic consisting of multiple overlapping, wavy lines in shades of gray, creating a sense of motion and depth across the lower half of the page.

Maxtang[®]

MAXIMIZING YOUR COMPUTING PRODUCTIVITY

Copyright

© 2021 Shenzhen Maxtang Computer Co., Ltd. All rights reserved. No part of this publication may be reproduced, copied, stored in a retrieval system, translated into any language, or transmitted in any form or by any means, electronic, mechanical, photocopying, or otherwise, without the prior written consent of Shenzhen Maxtang Computer Co., Ltd (hereinafter referred to as “Mxtang”).

Disclaimer

Mxtang reserves the right to make changes and improvements to the products described in this document without prior notice. Every effort has been made to ensure the information in the document is correct; however, Mxtang does not guarantee this document is error-free.

Mxtang assumes no liability for incidental or consequential damages arising from misapplication or inability to use the product or the information contained herein, nor for any infringements of rights of third parties, which may result from its use.

Trademarks

All the trademarks, registrations, and brands mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective owners.

FP50 User Manual

(Version 1.0)

Version:		
Version No.	Description	Date
V1.0	Initial Version.	2020/09/24
	Updated the memory capacity to maximum of 64GB	2021/03/22

Content

Chapter 1 Product Introduction	3
1.1 Brief Introduction	3
1.2 Parameters.....	3
1.3 Connector Diagram (Board)	4
1.4 Connector Diagram (Mini PC).....	5
Chapter 2 Hardware.....	6
2.1 Jumper Setting	6
2.2 Memory Slots	6
2.3 Display	6
2.4 Storage (Screen Printing: SATA, M.2_N, PWSATA).....	6
2.5 LAN.....	6
2.6 Audio	6
2.7 CPU FAN Socket (Screen Printing: CPUFAN)	6
2.8 CMOS Clearance/Retention (Screen Printing: CLR_CMOS).....	7

Chapter 1 Product Introduction

1.1 Brief Introduction

The FP50 motherboard is based on AMD Ryzen embedded/mobile processors.

1.2 Parameters

Ryzen Mobile Processors:

- Ryzen 5 2500U—Quad-Core, Base Freq. 2GHz, Max Freq. 3.6GHz, TDP 15W
- Ryzen 5 3500U—Quad-Core, Base Freq. 2.1GHz, Max Freq. 3.7GHz, TDP 15W
- 3020E—Dual-Core, Base Freq. 1.2GHz, Max Freq. 2.6GHz, TDP 6W
- R1305G—Dual-Core, Base Freq. 1.5GHz, Max Freq. 2.8GHz, TDP 8-10W

Memory: Dual Channel SO-DIMM DDR4 up to 64GB, Maximum Frequency 2400MHz.

GPU: Integrated graphics based on CPU, supports dual display via 2x HDMI2.0,

Storage: 1 x M.2 Key M for 2280 NVMe SSD (SATA SSD optional), 1x SATA3.0

USB: 3x USB3.2; 2xUSB2.0

Expansion: 1 x M.2 Key E 2230 for Wi-Fi & Bluetooth



Ethernet: 1xOnboard Gigabit Network Controller (Realtek RTL8111H)

Audio: High-Definition Audio Codec,1x Line-out, 1x Mic-in


Power: 12V DC-in

Working temperature: 0°C~50°C

1.3 Connector Diagram (Board)



1.4 Connector Diagram (Mini PC)



Chapter 2 Hardware

2.1 Jumper Setting

Please configure the jumpers according to your requirements before installing the hardware.

How to identify the first header of jumpers and pins: Observe the mark beside the jumper or pins and find the header marked by "1" or bold line or triangular symbol. Or observe the rear panel and the header with a square solder pad is the first header.

2.2 Memory Slots

2 x SO-DIMM DDR4-2400 MHz, supporting dual channels, maximum capacity 64GB.

2.3 Display

The board is equipped with two standard HDMI2.0 interfaces for display.

2.4 Storage (Screen Printing: SATA, M.2_N, PWSATA)

The board offers 1xM.2 Key M 2280 NVMe (SATA Optional) SSD.

It provides a standard SATA3.0 interface with a 4PIN hard disk power supply interface.

PWSATA (Screen Printing: PWSATA)

Pin	Signal
1	+5V
2	GND
3	GND
4	+5V

2.5 LAN

One RJ45 interface Gigabit Network Controller (RTL8111H) onboard, supports PXE network boot and Magic packet wake-up functions.

LED Status Indicators:

LINK LED(Green)	Function	ACTIVE LED(Orange)	Function
Always on	Network Connected	Blinking	Data transfer

2.6 Audio

The board features High-Definition Audio Codec ALC662, the audio interface colored green is the Line-out, the audio interface colored pink is the Mic-in.

2.7 CPU FAN Socket (Screen Printing: CPUFAN)

The board provides a CPU cooling fan socket for better heat dissipation.

CPUFAN (Screen printing: CPUFAN)

Pin	Signal
1	+5V
2	GND
3	TAC
4	CTL

2.8 CMOS Clearance/Retention (Screen Printing: CLR_CMOS)

Clearing CMOS will permanently erase the previous system settings and set them to the original (factory settings) system settings.

Step 1: Turn off the PC and disconnect the power adapter.

Step 2: Press the CLR_CMOS button for 10 seconds.

Step 3: Restart the device, press the button to enter the BIOS setting, load the optimal default value.

Step 4: Save and exit the settings.

 **Please do not clear COMS when the PC is connected to power in case board damages.**