

BW50 User Manual

(Version 1.0)

Version:		
NO.	Description	Issue Date:
V1.0	Initial Version	2020/05/23

Contents

BW50 User Manual.....	1
(Version 1.0)	1
Chapter 1 Product Introduction	3
1.1 Brief Introduction	3
1.2 Parameters	3
1.3 Connector Diagram.....	4
1.4 Mini PC I/O Interface.....	5
Chapter 2 Hardware	6
2.1 Installations	6
2.2 Jumper Setting	6
2.3 Memory Slots	6
2.4 Display Interfaces	6
2.5 Storage Interfaces	7
2.6 Expansion Slot	7
2.7 LAN	7
2.8 Audio Interface.....	7
2.9 CPU Fan (Screen printing: CPUFAN)	7
2.10 CMOS Clearance/Retention (Screen printing: CLR_CMOS)	7

Chapter 1 Product Introduction

1.1 Brief Introduction

The BW50 motherboard is a 4x4 compact small-form motherboard based on the 4th Gen and 5th Gen (Haswell-U/Broadwell-U) Intel Core i5/i7 processor, designed for various IoT solutions.

1.2 Parameters

CPU:

- Intel® Core™ i5-4200U Processor. 2Cores 4Threads, Max Turbo Frequency: 2.60GHz, Base Frequency: 1.60GHz, 3 MB Intel® Smart Cache, TDP: 15W.
- Intel® Core™ i7-4600U Processor. 2Cores 4Threads, Max Turbo Frequency: 3.30GHz, Base Frequency: 2.10GHz, 4 MB Intel® Smart Cache, TDP: 15W.
- Intel® Core™ i5-5200U Processor. 2Cores 4Threads, Max Turbo Frequency: 2.70GHz, Base Frequency: 2.20GHz, 3 MB Cache, TDP: 15W.
- Intel® Core™ i7-5500U Processor. 2Cores 4Threads, Max Turbo Frequency: 3.00GHz, Base Frequency: 2.40GHz, 4 MB Cache, TDP: 15W.

Memory: 2x SO-DIMM DDR3L Slots up to 16GB for maximum memory capacity.

GPU: Integrated Graphics based on CPU, dual displays via 2x HDMI2.0.

Storage: 1 x M.2 Key M slot for 2280 SATA SSD (NVMe optional), 1x SATA3.0 interface

USB: 3x USB3.0, 2x USB2.0

Expansion: 1x M.2_Key E slot, type 2230 for Wi-Fi and Bluetooth

Ethernet: One RTL8111H Network Controller on-board, Data Rate Per Port: 1.0Gbps

Audio: High-Definition Realtek Audio Codec,1x Line-out, 1x Mic-in.


Board Dimension: 120mm x 120 mm

Chassis Dimension: 130mm x 128 mm x52 mm


Power: 12V DC-in

Working Temperature: 0 °C~50 °C

1.3 Connector Diagram



1.4 Mini PC I/O Interface



Chapter 2 Hardware

2.1 Installations

Please refer to the following steps for installations:

1. Read the user manual carefully to make sure all the adjustments on the BW50 are correct.
2. Installing the Memory:
 - Press the ejector tab of the memory slot outwards with your fingertips.
 - Hold the memory module and align the key to the module with that on the memory slot.
 - Gently push the module into the slot until the ejector levers return completely to the closed position, holding the module in place when the module touches the bottom of the slot. To remove the module, press the ejector levers outwards to unseat the module.
3. Installing the expansion cards:
 - Locate the expansion slots and remove the screw, insert the cards into the slot at a 45-degree angle then attach the screw to the expansion cards, gently press down on it then install the screw back.
4. Connect all signal wires, cables, panel control wiring, and power supplies.
5. Start the computer and complete the setup of the BIOS program.

The board's components are integrated circuits and can easily be damaged by Electrostatic Discharge or ESD; therefore, please follow the instructions:

- Hold the board's edge when handing, and do not touch onboard pins, components, or plug sockets.
- When touching integrated circuit components (such as CPU, RAM, etc.), please wear an anti-static wrist strap/glove to avoid electrostatic discharge damage to the board or other sensitive components.
- Before installing the integrated circuits/sensitive components, place the sensitive components in anti-static bags to keep them safe from ESD.
- Please make sure the power switch is OFF before plugging the power plug.

2.2 Jumper Setting

Please configure the jumpers according to your requirements before installing the hardware.

How to identify the first header of jumpers and pins: Observe the mark beside the jumper or pins and find the header marked by "1" or bold line or triangular symbol. Or observe the rear panel and the header with a square solder pad is the first header.

2.3 Memory Slots

The board provides two SO-DIMM DDR3L-1600MHz slots up to 16GB for memory.

Notes: Make sure to hold the memory module and align the key to the module with that on the memory slot. While choosing a memory module, please make sure the module matches the board's specifications.

2.4 Display Interfaces

The board features two HDMI2.0 standard interfaces.

2.5 Storage Interfaces

The board provides 1x M.2 Key_M slot for 2280 SATA/NVMe SSD, 1x SATA3.0 interface and a 4PIN hard disk power supply interface.

PWSATA (Screen Printing: PWSATA)

Pin	Signal
1	+5V
2	GND
3	GND
4	+5V

2.6 Expansion Slot

The board provides 1x M.2_Key_E slot, type 2230 for Wi-Fi and Bluetooth.

2.7 LAN

The board features 1xRJ45 LAN interface with high-speed RTL8111H network controller, data rate per ports: 1.0Gbps. It supports network wake-up (Magic packet wake-up) and UEFI PXE network boot.

LED Status Indicators:

LI_LED Status (Green)	Function	ACT_LED Status (Orange)	Function
Always on	Network Connected	Flashing	Data transmission

2.8 Audio Interface

The board features a Realtek ALC662 High-Definition Audio Codec, supports 1x Line-out(Green) and 1x Mic-in(Pink).

2.9 CPU Fan (Screen printing: CPUFAN)

The board features one cooling fan socket for better heat dissipation.

CPUFAN (Screen Printing: CPUFAN)

Pin	Signal
1	+5V
2	GND
3	CPUFAN_TAC
4	CPUFAN_CTL

2.10 CMOS Clearance/Retention (Screen printing: CLR_CMOS)

CMOS is powered by onboard button batteries. Clearing CMOS will permanently remove the previous system settings and restore the board system to original settings (factory settings).

Step 1: Turn off the PC and disconnect the power.

Step 2: Press CLR_CMOS for 10 seconds then disconnect.

Step 3: Restart the device, press the button to enter the BIOS, load the optimal default value,

Step 4: save, and exit the settings.



Please do not clear COMS when the PC is connected to power in case board damages.